


TORNADO OSD update guide


1、Unpack the file



2、Install the driver




3、Power on the TORNADO OSD and connect the update kit to the main board as shown on the pictures below.






4、 Clicking on **TORNADO Flight control.exe**



The update progress is as above, DO NOT disconnect the update kit or cut off the power supply of TORNADO OSD.



Click on OK to finish the update then cut off the power of TORNADO OSD and remove the update kit.

- 5、 The OSD will enter auto detection mode during the first power on, connect GPS module and the main board should be placed strictly horizontally and statically, avoid any movement or vibration. If there is any error during the detection, there will be error shows on the OSD screen, cycle the power and do it again.
- 6、 When the detection is done, the OSD screen will enter the working mode, please set all your configurations one time again, specially, don't forget to reset the GYRO and confirm the SEV CENTER items.